


Chassé[®] Zone Shoe (S1801)

CHOOSING YOUR SIZE WITH SHOE SIZERS

Find the right fit for your cheer shoes with Shoe Sizers.

Not all cheer shoe styles fit the same and some have recommended sizes smaller or larger than your usual street shoe size. These Shoe Sizers fit like the insole of the cheer shoe, so please follow the instructions below.



Suggested sizes for the Chassé Zone Shoe (S1801):

Measuring the insole of one of your existing shoes is a good way to ensure a proper fit.

US SIZE	SUGGESTED SIZE	INSOLE LENGTH (in)	INSOLE WIDTH (in)	US SIZE	SUGGESTED SIZE	INSOLE LENGTH (in)	INSOLE WIDTH (in)	US SIZ	SUGGESTED SIZE	INSOLE LENGTH (in)	INSOLE WIDTH (in)
6Y	8Y			1 ^{1/2} Y	′ 3Y	8 5/8	2 7/8	8	81/2	10 1/4	3 ^{1/4}
7Y	9Y			2Y	4	8 3/4	2 7/8	81/2	81/2	10 3/8	3 1/4
8Y	10Y	6 7/8	2 3/8	21/2	Y 4	8 7/8	3	9	9	10 1/2	3 1/4
9Y	11Y	7 ^{1/8}	2 1/2	3Y	41/2	9	3	91/2	91/2	10 5/8	3 3/8
10Y	11 ^{1/2} Y	7 3/8	2 1/2	4	5	9 ^{1/4}	3	10	10	10 3/4	3 3/8
11Y	12-12 ^{1/2} Y	′ 7 ^{3/4}	2 5/8	41/2	51/2	9 ^{3/8}	3	101	² 10 ^{1/2}	10 7/8	3 3/8
11 ^{1/2} Y	13Y	7 7/8	2 5/8	5	6	9 ^{1/2}	3	11	11	11	3 3/8
12Y	13 ^{1/2} Y	8	2 5/8	51/2	6	9 ^{5/8}	3 ^{1/8}	12	12	11 ^{1/4}	3 ^{1/2}
12 ^{1/2} Y	′ 1Y	8 1/8	2 3/4	6	61/2	9 ^{3/4}	3 ^{1/8}	13	13	11 ^{1/2}	3 ^{1/2}
13Y	1 ^{1/2} Y	8 1/4	2 3/4	61/2	7	9 ^{7/8}	3 ^{1/8}	14	14	11 3/4	3 ^{1/2}
13 ^{1/2} Y	′ 2Y	8 3/8	2 3/4	7	71/2	10	3 ^{1/8}				
1Y	2 ^{1/2} Y	8 1/2	2 3/4	71/2	8	10 1/8	3 ^{1/4}				

Recommended sizing for each style and brand of cheer shoe varies. Use the Shoe Sizer for same style you are ordering. Shoe Sizer fitting is a suggestion and not a guarantee on the fit. Allowances may be needed for wider or higher feet. For questions call 1-800-299-7822.